

SKRUVSATS STEP 40/90

5220



Skrusats innehållande 4st M4 x 8. Passar till

- STEP 30 Preload
- STEP 40 Preload
- STEP 90 Preload
- STEP 98 Preload
- STEP 90 Release